



MODEL NO. :316

INSTRUCTION MANUAL

JMD

AC/DC OPERATED
RECHARGEABLE FAN WITH
SUPER BRIGHT LED LIGHT



1. Red LED charging indicator

2. Green LED operating indicator

3. LED light switch

4. Power Switch & Speed Control

5. LED Light
6. AC plug socket

7. Double DC output for 6V LED bulb

8. USB output for 5V Cellphone charger with multi cable

9. DC 9V input

10.Oscillation control lock

Thank you for using our product, please read the instruction manual carefully before initial use.

Please read these instructions before first use:

- 1.Handle

2.Back cover

3.Fixed ring of grill

4.Fan blade

5.Fixed knob of blade


6.Big fixed ring

7.Front cover

8.Protecting cover

9.Battery

10.Battery cover



ATTENTION

- 1.Please read this instruction before first use.

2.Please ensure that the voltage indicated on the appliance corresponds with the mains voltage.

3.When the led gets dim, please recharge the product.

4.Charge at least once in every 3 months for 8hours even when the appliance is not in use.

5.Please keep the fan switch in OFF status when not in use.

6.Suitable operating ambient humidity level is 0℃-40℃.

7.Avoid using in water or moist.

HOW TO OPERATE

- 1.Make sure the power supply is consistent with the rating of product.

2.Connect the power supply, the charge indicator turn green, then the fan can work.

FUNCTION

- ON/OFF: Turn on or turn off the fan

1-2 and control fan speed

Turn: Oscillation control lock

LED: Turn on or turn of LED light



HOW TO ASSEMBLE THE FAN

- 1.Take connector through studdle, and fix studdle to bottom base as picture 1.

2.Connect the battery line; please see "HOW TO CHANGE THE BATTERY" for reference.

3.Fix all parts as shown in picture 3, but knob of blade must be fixed anti clockwise.


4.As shown in picture 4, fan is complete.

210 mm

140 mm

140 mm

正面



HOW TO CHANGE THE BATTERY

- 1.Loosen the fixing screw on the battery cover.

2.Take out the battery cover.

3.Pull out the battery terminal and take out old battery.

4.Put inside the new battery, and connect '⊕' to red cord, ⊖ to black cord, must follow it.

5.Put the cover and tighten the screw.



HOW TO CHARGE THE FAN

- 1.Please ensure that the voltage indicated on the appliance corresponds with the mains voltage.

2.Plug in the cord to AC socket.

3.Red indicator shows that the battery is getting charged.

4.It is a normal phenomenon of slight heat while charging the battery.

TECHNICAL DATA

- 1.Power source: 110-240V 50/60Hz

2.Battery: 6V 4.5Ah sealed lead-acid rechargeable battery

3.Light source: 6pcs 0.2W LED

4.Blade: 16 inch

